OKI
People to People Technology™

C7000 SERIES

Installing the Duplex Unit

OKI P/N 70037201

Install the Duplex Unit

! *If you will be using the duplex unit to print complex documents or graphics, you will need to purchase and install additional memory. For Models C7200 and C7200n, add 64 MB memory (OKI # 70037401). For Model C7400n, add 128 MB memory (OKI # 70037501)*

1 Unpack the duplex unit and remove any shipping materials.

2 Turn the printer off, then open the front cover.

3 Locate the slides inside the printer.



4 Place the duplex unit guide rails on the slides, then push the duplex unit all the way into the printer.



5 Close the front cover.



Activate the Duplex Unit in the Driver

Windows PCL Driver

1 Click **Start** → **Settings** → **Printers**.
*The **Printers** dialog box opens.*

2 Right click the OKI C7200 or C7400 PCL printer icon, then click **Printing Preferences** (Windows 2000), **Properties** (Windows Me, 98, 95) or **Document Defaults** (Windows NT 4.0).

3 In the **Paper** tab, click **Device options**.

4 Click **Duplex option unit** to select it, then click **OK**.

5 Click **OK**, then close the **Printers** dialog box.

Windows PostScript Driver

1 Click **Start** → **Settings** → **Printers**.
*The **Printers** dialog box opens.*

2 Right click the OKI C7200 or C7400 PostScript printer icon, then click **Properties**.

3 ***Windows 2000 and NT 4.0:***

a Click the Device Settings tab.

b Scroll down to Installable Options and click Duplex.

c Under Change 'Duplex' Setting, click Installed.

Windows Me, 98 and 95:

a Click the Device Options tab.

b Click Duplex.

c Under Change setting for: Duplex, click Installed.

4 Click **OK**, then close the **Printers** dialog box.

Macintosh Driver

1 Activate **Chooser** from the **Apple** menu.

2 Select **LaserWriter 8**.

3 Click **Printer** → **Setup**.

4 Click **Configure**.

5 Change the **Duplex** setting to **Installed**.

6 Click **OK** twice.

7 Close **Chooser**.

Limited Warranty: United States

Oki Data Americas, Inc. (Oki Data) warrants this OPTION to be free from defect in material and workmanship and will remedy any such defect according to the terms of this *Limited Warranty.*

Oki Data will repair (or at its option, replace) at no charge, any defective part(s) of the OPTION for one (1) year from the date of purchase. This *Limited Warranty* extends to the original purchaser only.

To make request or claim for service under this Limited Warranty the original purchaser must return the Oki Data product, shipping prepaid, in the original shipping container or equivalent, to Oki Data or an authorized Oki Data service center and assume the risk of loss or damage in transit. A written receipt for the product, showing the date of purchase, dealer's name, and item purchased must accompany any request or claim for work to be performed under this Limited Warranty.

This *Limited Warranty* shall not apply if the product has been damaged due to abuse, misuse, misapplication, accident, or as a result of service or modification by any other than an authorized Oki Data service center.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE ON THE FACE HEREOF AND DESCRIBED ABOVE. NO WARRANTIES WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL EXTEND BEYOND THE RESPECTIVE WARRANTY PERIOD DESCRIBED ABOVE OF ONE (1) YEAR. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

OKI DATA SHALL NOT BE RESPONSIBLE OR LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSS ARISING FROM THE USE OF THIS PRODUCT. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion may not apply to you.

Additional information on obtaining service under this *Limited Warranty* is available by contacting the Oki Data dealer from whom the product was purchased, by contacting Oki Data directly at 1-800-OKI-DATA (U.S. and Canada), or by contacting one of the service depots listed.

This *Limited Warranty* applies to this Oki Data Option. However, the procedure for obtaining service may vary outside the continental United States. Contact your Oki Data dealer for such warranty service information.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For the most comprehensive, up-to-date listing of Oki Data authorized Service Centers, call 1-800-OKI-DATA (1-800-654-3282).

Oki Data Service Centers

UNITED STATES
Oki Data Americas, Inc.
Tel: 1-800-654-3282
Fax: 1-856-222-5247

CANADA
Oki Data Americas, Inc.
Tel: 800-654-3282
Fax: 905-238-4427

MEXICO
Oki Data de Mexico, S.A. de C.V.
Tel: (525) 263-8780
Fax: (525) 263-8785

BRAZIL
Oki Data do Brasil, Ltda.
Tel: 5511-5011-1518
Fax: 5511-5012-0267

Oki Data Americas, Inc., 2000 Bishops Gate Blvd., Mt. Laurel, NJ 08054-4620
Tel: (800) 654-3282 FAX: (856) 222-5320 http://www.okidata.com

58346501